



..... COMPLETE HEAT MOLD

Used to fully customize the entire fit of your Jet Carbon boots

HOW TO COMPLETE HEAT MOLD

1. Unmount and remove the plate
2. Preheat oven to 85°C/185°F
 - *If you are unsure of your oven's temperature accuracy, DO NOT PROCEED Over heating the boots will cause permanent damage and will void the warranty*
3. Place boots in the oven for 10 minutes
4. Remove boot from oven - use oven mitts to prevent burning hands in oven
5. Let boots cool for 1 minute
6. While sitting, place feet into boots, tie securely and stand
7. Stand still in the boot for 5-10 minutes while the boots cool
 - *Do not move around or you may improperly mold the boot*
 - *Do not bend the boot as you will damage the carbon outsole*
8. Once the boot has cooled, remount the plate

WHEN to complete heat mold?

- Complete heat mold when the boot is new, before skating
- Complete heat mold must be done with the plate removed

ITEMS needed:

- Oven
- Oven Mitts
- Smooth floor

CAUTION!

Do not heat mold the boot with the plate installed or you may risk burning yourself and improperly molding the boot

Failure to follow procedure precisely will permanently damage the boots and void the warranty