



## COMPLETE HEAT MOLD

*Used to fully customize the entire fit of your Jet Carbon boots*

### HOW TO COMPLETE HEAT MOLD

1. Unmount and remove the plate
2. Preheat oven to 85°C/185°F
  - ▶ *If you are unsure of your oven's temperature accuracy, DO NOT PROCEED Over heating the boots will cause permanent damage and will void the warranty*
3. Place boots in the oven for 10 minutes
4. Remove boot from oven - use oven mitts to prevent burning hands in oven
5. Let boots cool for 1 minute
6. While sitting, place feet into boots, tie securely and stand
7. Stand still in the boot for 5-10 minutes while the boots cool
  - ▶ *Do not move around or you may improperly mold the boot*
  - ▶ *Do not bend the boot as you will damage the carbon outsole*
8. Once the boot has cooled, remount the plate

**WHEN** to complete heat mold?

- ▶ Complete heat mold when the boot is new, before skating
- ▶ Complete heat mold must be done with the plate removed

**ITEMS** needed:

- ▶ Oven
- ▶ Oven Mitts
- ▶ Smooth floor

### **CAUTION!**

*Do not heat mold the boot with the plate installed or you may risk burning yourself and improperly molding the boot*

*Failure to follow procedure precisely will permanently damage the boots and void the warranty*